

Speed Wildcat XX Window Nets Install Guide

Tools needed: 3/16" hex key



1. Place brackets at **A**, **B**, and **C**. The bracket with the large hole in it goes at **C**. Position them so that the bolts are on the interior of the vehicle.
2. Snug all bracket bolts so the brackets do not move, but still may be turned by hand.
3. Attach frame to front pin hinges at **A** and **B**. Door handle should be on the interior.
4. Shim bottom of window net at **D** so that the bottom of the window net is about 1/8" above the door.



5. Position window net so that there is very little clearance between frame and seat belt bolt by **C**. Position by rotating/moving brackets at **A** and **B**.



7. Align latch pin with bracket at **C** by pulling the pin, aligning bracket, and then releasing pin so it goes into the bracket hole. As pictured in step 5.
8. Tighten all bracket bolts. Open and close window and adjust as needed.

6. Mount ball stud to vehicle frame at **E**. Press gas spring shock on to ball studs on window net and vehicle at **E** and **F**.

